


INSTALLATION INSTRUCTIONS



IMPORTANT

Before opening your Lights.com fixture, please make sure that you carefully read through these instruction sheets. Consider having your fixture installed by a qualified licensed electrician.

NOTE: The important safeguards and instructions that appear in this manual are not meant to cover all possible conditions and situations that may occur. It must be understood that common sense, caution and care, are factors that can't be built into any product. This approach must be used by the person(s) caring for and operating the fixture.



GENERAL INFORMATION

All electrical connections must be in accordance with all ordinances, local and national electrical codes. These fixtures are intended for mounting to a standard 4" x 2-1/2" metal octagon outlet box. The box must be directly supported by the building structure and UL Recognized.

STEP BY STEP INSTRUCTIONS

Before starting your installation, disconnect the power by turning off the circuit breaker or by removing the fuse at the fuse box. Just turning the light off at the light switch is not sufficient to prevent electrical shock.


COLLECTION	APPLICATION	MODEL NO.
Alton with Tapered Bell	Wall Sconce	LC003546
		LC003547

WHAT WE PROVIDE

- Mounting & Wiring Hardware
- Glass Shade
- Allen Key


WHAT YOU NEED

- Phillips Screwdriver
- Wire Cutters
- Wiring Supplies as Specified by Electrical Code
- 1 x 60W E26 Bulb



1

UNPACK FIXTURE



2

PREPARE FIXTURE AND MOUNTING PLATE


Remove the mounting plate from the backplate by unscrewing the side screws from the backplate.



3

INSTALL THE MOUNTING PLATE

If there is an existing fixture, remove it. Expose the supply wires from the J-Box. Insert supply wires through the mounting plate. Secure the mounting plate using the two Phillips head screws provided. Tighten to secure.



4

INSTALL SOCKET ONTO GLASS

Unscrew the decorative nut from the socket and remove the decorative washer, rubber washer, and decorative nut from the fixture wires. Make sure the small rubber washer is on top of the socket and then feed fixture wires through the inside of the glass and out through the top hole of the glass. Insert the rubber washer, decorative washer, and decorative nut back onto the fixture wires on top of the glass. Thread the decorative nut onto the socket by turning the decorative nut clockwise.



5

INSTALL SOCKET ONTO FIXTURE ARM


Loosen two Allen screws from the decorative nut, using the Allen key provided. Thread fixture wires through the fixture arm and out through the backplate. Insert the fixture arm into the decorative nut and secure the two Allen screws using the Allen key. Hand tighten to secure.



6

MAKE WIRE CONNECTIONS


Connect the BLACK fixture wire to the BLACK supply wire and the WHITE fixture wire to the WHITE supply wire. Connect the fixture ground wire to the J-BOX ground wire. Secure all connections with the supplied wire nuts and electrical tape (not supplied).



7

CONNECT FIXTURE TO THE MOUNTING PLATE

Position backplate over the mounting plate. Align the holes on the sides of the mounting plate with the two holes on the sides of the backplate and secure with the supplied screws.




8

INSTALL THE BULB

Insert the bulb.

MAXIMUM WATTAGE 60W.

DO NOT EXCEED THE WATTAGE AS STATED ON THE WARNING LABEL.



9

RESTORE THE ELECTRICITY AND CHECK THE OPERATION OF YOUR NEW FIXTURE

CAUTION

Please ensure that the fitting is cool and switched off before replacing the bulb. DO NOT use bulbs that might exceed the maximum wattage, stated on caution label.

DIMMER NOTE

For the best lighting experience, we recommend using a dimmer. Not only does this allow you to create a great ambiance, it allows for energy savings and extends the life of the bulbs.