

INSTALLATION INSTRUCTIONS



IMPORTANT

Before opening your Lamplust Rosalind Textured Slim Pillar Candles, please make sure that you carefully read through these instruction sheets.


NOTE: The important safeguards and instructions that appear in this manual are not meant to cover all possible conditions and situations that may occur. It must be understood that common sense, caution and care are factors that can't be built into any product. This approach must be used by the person(s) caring for and operating the candles.

GENERAL INFORMATION

Battery installation should only be performed by an adult. Only batteries of the same or equivalent type as recommended should be used. Battery leakage can cause corrosion and damage to this product so please remove non-functioning batteries immediately. Remove the batteries from product during long periods of non-use. DO NOT DISPOSE OF IN FIRE. Please dispose at your local recycling facility.

STEP BY STEP INSTRUCTIONS

Before turning on your candles, remove the plastic from around the batteries and insert them into the the battery compartment.




MODEL NO.

LC003702
LC003703

WHAT WE PROVIDE


- Four Rosalind Textured Slim Pillar Candles
- 8 AA Batteries (2 Per Candle)
- 6 Button Remote Control



BATTERY INSTALLATION

The candles work with 2 x AA batteries (included). Batteries should be inserted with the correct polarity as indicated (+/-) and battery compartments secured before use.


INSTALLATION INSTRUCTIONS



2

ON/OFF

The ON/OFF switch is located on the bottom of the candle, below the battery compartment. Once the candle is turned on position it can be controlled using the remote, until it is manually turned off. To maximize battery life, manually turn candle off during long periods of non-use.



3

REMOTE FUNCTIONS

The candle must be manually turned on in order for the remote control to function.