



IMPORTANT

Before using your Lamplust Charlotte Pampas Grass Asymmetrical Wreath, make sure that you carefully read through these instruction sheets.

NOTE: The important safeguards and instructions that appear in this manual are not meant to cover all possible conditions and situations that may occur. It must be understood that common sense, caution and care are factors that can't be built into any product. This approach must be used by the person(s) caring for and operating the lantern.


GENERAL INFORMATION

The wreath is meant for indoor use only. DO NOT attempt to replace or repair any damaged wire parts. After use, ensure the wreath is clean and dry before storage.

Battery installation should only be performed by an adult. Only batteries of the same or equivalent type as recommended should be used. Battery leakage can cause corrosion and damage to this product so please remove non-functioning batteries immediately. Remove the batteries from the wreath during long periods of non-use. DO NOT DISPOSE OF IN FIRE. Please dispose at your local recycling facility.


STEP BY STEP INSTRUCTIONS

Before using your wreath, remove all packaging pieces. When setting up your wreath, carefully position wires to avoid a tripping hazard.



WHAT WE PROVIDE


- Charlotte Pampas Grass Asymmetrical Wreath with 48 LEDs
- 3 x AA Battery Box
- Decorative Fabric Bag to Conceal Battery Box



1

BATTERY INSTALLATION

The wreath works with 3 x AA batteries. Batteries should be inserted with the correct polarity as indicated (+/-) and battery compartment secured before use.



2

ON/OFF/TIMER

To utilize the 6-hour timer function, move the battery box switch to the center. Once set, the wreath will turn on and off at the same time each day. Move the switch all the way to the right to turn on the wreath with no timer.



3

STYLE AND HANG YOUR WREATH

The branches on the wreath can come tightly packed for shipping purposes. Separate the branches and style the ribbon for your desired look. Be sure that the wreath is hung on a nail, screw, or hook that is strong enough to support the weight of the wreath and batteries.



4

CONCEALING THE BATTERY BOX

Place the battery box inside the included decorative fabric bag to keep it hidden from view. Tie the drawstring and hang or place accordingly.