



IMPORTANT

Before using your LampLust Glass Eggs, please make sure that you carefully read through these instruction sheets.

NOTE: The important safeguards and instructions that appear in this manual are not meant to cover all possible conditions and situations that may occur. It must be understood that common sense, caution and care are factors that can't be built into any product. This approach must be used by the person(s) caring for and operating the glass eggs.



GENERAL INFORMATION

Battery installation should only be performed by an adult. Only batteries of the same or equivalent type as recommended should be used. Battery leakage can cause corrosion and damage to this product so please remove non-functioning batteries immediately. Remove batteries from the product during long periods of non-use.

DO NOT DISPOSE OF IN FIRE. Please dispose at your local recycling facility.

STEP BY STEP INSTRUCTIONS

Before turning on the eggs, locate the AAA batteries inside of the foam packaging. Then, remove the plastic from around the batteries and insert them into the battery compartment (located on the bottom of the eggs). For the smaller egg, the batteries are pre-installed. To activate the batteries, remove the clear battery tab from the battery compartment.




WHAT WE PROVIDE


- 3 x Glass Eggs
- 2 x CR2032 Batteries
- 6 x AAA Batteries

AAA BATTERY INSTALLATION

The Green and Pink eggs work with 3 AAA batteries each. Batteries should be inserted with the correct polarity as indicated (+/-) and battery compartments secured before use.

**2****CR2032 BATTERY INSTALLATION**

The Purple egg works with 2 CR2032 MAX or CR2032 batteries. The battery compartment is located on the bottom of the egg. The battery box has a little metal tab. Lift the tab slightly and insert the batteries between the tab and the spring. Push the tab back down to secure before replacing the plastic battery cover. Batteries should be inserted with the correct polarity as indicated (+/-) and battery compartments secured before use.

**3****SWITCH OPTIONS**

The OFF/ON switch is located on the bottom of the eggs, below the battery compartment.