




IMPORTANT

Before assembling your Ghost and Pumpkin String Lights, please make sure that you carefully read through these instruction sheets.

NOTE: The important safeguards and instructions that appear in this manual are not meant to cover all possible conditions and situations that may occur. It must be understood that common sense, caution and care are factors that can't be built into any product. This approach must be used by the person(s) caring for and operating the string lights.



GENERAL INFORMATION

These string lights are suitable for indoor and outdoor use.

DO NOT attempt to replace or repair any damaged cable parts.

After use, ensure the string light set is clean and dry before storage. Battery installation should only be performed by an adult.

Only batteries of the same or equivalent type as recommended should be used. Battery leakage can cause corrosion and damage to this product so please remove non-functioning batteries immediately. Remove the batteries from product during long periods of non-use.

DO NOT DISPOSE OF IN FIRE. Please dispose at your local recycling facility.

DO NOT submerge any part of the string lights in water. The string lights are water RESISTANT only

WHAT WE PROVIDE

- Set of 2 String Lights:
 - 1 Strand of Ghost Lights and
 - 1 Strand of Pumpkin Lights
- 2 Decorative Fabric Bags to Conceal Battery Boxes


WHAT YOU NEED

- 4 AA Battery Box with Timer/On/Off Button (2 Per Light Strand)

STEP BY STEP INSTRUCTIONS

Before installing your string lights, remove packaging. When setting up the string lights, carefully position cables to avoid a tripping hazard.


When hanging lights, use a stable method of support.



1

BATTERY INSTALLATION

Each set of string lights works with 2 x AA batteries. Batteries should be inserted with the correct polarity as indicated (+/-) and battery compartment secured before use.



2

BUTTON OPTIONS

Press the button once to activate the 6-hour timer. Once the timer is activated, the string lights will turn on and off at the same time each day. Press the button a second time, and the light will turn on without the timer function. Press the button a third time to turn off the lights.