



**IMPORTANT**

Before opening your LampLust Shimmering Angel Flameless Pillar Candle Trio, please make sure that you carefully read through these instruction sheets.

**NOTE:** The important safeguards and instructions that appear in this manual are not meant to cover all possible conditions and situations that may occur. It must be understood that common sense, caution and care are factors that can't be built into any product. This approach must be used by the person(s) caring for and operating the candles.

**GENERAL INFORMATION**

Battery installation should only be performed by an adult. Only batteries of the same or equivalent type as recommended should be used. Battery leakage can cause corrosion and damage to this product so please remove non-functioning batteries immediately. Remove the batteries from product during long periods of non-use.

DO NOT DISPOSE OF IN FIRE. Please dispose at your local recycling facility.


**STEP BY STEP INSTRUCTIONS**

Before turning on your candles, remove the battery tab from the battery compartment (located on the bottom of the candle), thereby activating the batteries.



**WHAT WE PROVIDE**

- Three Flameless Pillar Candles
- 6 AA Batteries (2 Per Candle)



1

**BATTERY INSTALLATION**

The candles work with 2 x AA batteries (included). Batteries should be inserted with the correct polarity as indicated (+/-) and battery compartments secured before use.

**2****SWITCH OPTIONS**

The ON/OFF switch is located on the bottom of the candle, below the battery compartment. To turn the candle ON/OFF use the switch located on the bottom. These candles have an automatic built-in 5-hour timer. Once the switch is turned to "ON", the candles will turn on and off at the same time each day.