

## INSTALLATION INSTRUCTIONS



### IMPORTANT

Before assembling your 12ft. Battery-Operated Green Wire Fairy Lights, please make sure that you carefully read through these instruction sheets.


**NOTE:** The important safeguards and instructions that appear in this manual are not meant to cover all possible conditions and situations that may occur. It must be understood that common sense, caution and care are factors that can't be built into any product. This approach must be used by the person(s) caring for and operating the string lights.

### GENERAL INFORMATION

The string light is suitable for indoor and outdoor use. DO NOT attempt to replace or repair any damaged cable parts. After use, ensure the string light set is clean and dry before storage.

DO NOT DISPOSE OF IN FIRE. Please dispose at your local recycling facility.

DO NOT submerge any part of the string lights in water. The string lights are water RESISTANT only.




### MODEL NO.

LC003668  
LC003673  
LC003674  
LC003675

### WHAT WE PROVIDE

- 60 LEDs on Wire
- 3 AA Battery Box with Button
- 3 White Fabric Bags



# 1

### BATTERY INSTALLATION

Battery installation should only be performed by an adult. Only batteries of the same or equivalent type as recommended should be used. Batteries should be inserted with the correct polarity as indicated (+/-) and battery components secured before use. Battery leakage can cause corrosion and damage to this product so please remove non-functioning batteries immediately. Remove the batteries from product during long periods of non-use.



# 2

## **BUTTON OPTIONS**

Press the button once to activate the 6-hour timer.  
Press the button again, the light will turn on without the timer function. Press the button a third time to turn off the lights.