




## IMPORTANT

Before opening your Lamplust Flameless Ivory Wax Drip Tea Lights, please make sure that you carefully read through these instruction sheets.

**NOTE:** The important safeguards and instructions that appear in this manual are not meant to cover all possible conditions and situations that may occur. It must be understood that common sense, caution and care are factors that can't be built into any product. This approach must be used by the person(s) caring for and operating the tea lights.



## GENERAL INFORMATION


Battery installation should only be performed by an adult. Only batteries of the same or equivalent type as recommended should be used. Battery leakage can cause corrosion and damage to this product so please remove non-functioning batteries immediately. Remove the batteries from product during long periods of non-use. DO NOT DISPOSE OF IN FIRE. Please dispose at your local recycling facility.

## WHAT WE PROVIDE

- Twelve Flameless Ivory Wax Drip Tea Lights
- 12 CR2032 MAX batteries (1 Per Tea Light)
- 6 Button Remote Control

## STEP BY STEP INSTRUCTIONS


Before turning on your tea lights, remove the battery tab from the battery compartment (located on the bottom of the tea light), thereby activating the battery.



# 1

## BATTERY INSTALLATION


Each tea light works with 1 x CR2032 MAX battery (included). The battery compartment is located on the bottom of the tealight. Secure battery compartment before use.



# 2

## ON/OFF SWITCH

The on/off switch is located on the bottom of the tea light, below the battery compartment. To turn the tea light on/off use the switch located on the bottom. Once the tea light is turned to the “ON” position it can be controlled using the remote, until it is manually turned to “OFF”.



# 3

## REMOTE FUNCTIONS

The tea light switch must be turned on in order for the remote control to function.