

INSTALLATION INSTRUCTIONS



IMPORTANT

Before opening your LampLust Victoria 10" Flameless Taper Candles, please make sure that you carefully read through these instruction sheets.

NOTE: The important safeguards and instructions that appear in this manual are not meant to cover all possible conditions and situations that may occur. It must be understood that common sense, caution and care, are factors that can't be built into any product. This approach must be used by the person(s) caring for and operating the candles.


GENERAL INFORMATION

Battery installation should only be performed by an adult. Only batteries of the same or equivalent type as recommended should be used. Battery leakage can cause corrosion and damage to this product so please remove non-functioning batteries immediately. Remove the batteries from product during long periods of non-use.

DO NOT DISPOSE OF IN FIRE. Please dispose at your local recycling facility.

STEP BY STEP INSTRUCTIONS

Before turning on your candles, remove the plastic from around the batteries and insert them into the the battery compartment.



MODEL NO.


LC003980

LC003981

LC003982

WHAT WE PROVIDE

- Four 10" Flameless Taper Candles
- 8 AAA Batteries (2 Per Candle)
- 6 Button Remote Control




1

BATTERY INSTALLATION

The candles work with 2 x AAA batteries (included). To locate the battery compartment remove the flame from the candle by pulling up. To open the battery compartment, unscrew the base from the battery compartment (clockwise). Batteries should be inserted with the correct polarity as indicated (+/-) and battery compartments secured before use.


INSTALLATION INSTRUCTIONS



2

ON/OFF

Once the batteries are installed, put the battery compartment & flame back into the wax shell and push the flame down to turn on. Push the flame down again to turn off. To maximize battery life, manually turn the candle off during long periods of non-use.



3

REMOTE FUNCTIONS

The candle must be manually turned on in order for the remote control to function.