



IMPORTANT

Before opening your LampLust Ignis Solar Lanterns, please make sure that you carefully read through these instruction sheets.

NOTE: The important safeguards and instructions that appear in this manual are not meant to cover all possible conditions and situations that may occur. It must be understood that common sense, caution and care are factors that can't be built into any product. This approach must be used by the person(s) caring for and operating the lanterns.


GENERAL INFORMATION

Battery installation should only be performed by an adult. Only batteries of the same or equivalent type as recommended should be used. Battery leakage can cause corrosion and damage to this product so please remove non-functioning batteries immediately. Remove the batteries from product during long periods of non-use.

DO NOT DISPOSE OF IN FIRE. Please dispose at your local recycling facility.


STEP BY STEP INSTRUCTIONS

Before operating your solar lights, remove packaging and ensure that the switch (located on the base of the housing cover), has been moved to "ON". The solar light must be turned on in order for the battery to charge.



WHAT WE PROVIDE


- Two Ignis Solar Lanterns
- 2 AA Ni-Mh Rechargeable Batteries (1 Per Lantern)



1

CHOOSING THE RIGHT LOCATION

Before setting up the solar lights, you will need to select the right location for installation. The solar lights need to be in a non-shaded area where sunlight is not obstructed by buildings, walls, trees, bushes or any shadows that these objects create throughout the day. Shady locations will not allow the battery to fully charge and may reduce the time the solar lights stay on. Avoid proximity to other light sources, which may cause the solar lights to not operate correctly.



2

SOLAR CHARGING

Maximum sunlight will give the internal battery the best charge and give you the best results. The solar light will not be very bright or long lasting, until the battery is fully charged. Once charged, the solar light will turn on at dusk and remain on for up to 8 hours, depending on the charge received that day.

NOTE: You may charge the battery in a battery charger, or charge it with the solar panel. When using the solar panel, be sure that the battery receives a full day's worth of sunlight before use.



3

ON/OFF SWITCH

The ON/OFF switch is located on the base of the housing cover. Twist the housing cover counter-clockwise until unlatched from the hooks. Use this switch to turn the lantern on or off. The solar light must be turned on in order for the battery to charge.



4

BATTERY REPLACEMENT

Batteries may need replacement every 1-2 years depending on the operating conditions. To install a new battery, carefully twist the housing for the LED counter-clockwise until it is unfastened from the cover. Note: Do not detach the wires attached to the cover and LED housing. When installing new batteries be sure to insert the battery with the correct polarity as indicated (+/-) and battery compartment secured before use.

TROUBLESHOOTING

Solar lanterns not operating properly at night may be caused by one of the following conditions:

- The switch may not be in the "ON" position. Ensure that the switch is in the "ON" position.
- Low light levels during the day, caused by the position in which the light is placed, weather conditions, or lack of sunlight, will shorten the solar lantern's operating time at night.
- If the solar panel surface is dirty, the charging ability will be reduced. Clean the surface occasionally with a damp cloth.
- The batteries might need to be replaced. In the event they do need replacing, see "BATTERY REPLACEMENT" above.
- Please note that the solar lanterns will not function in the daytime or in a brightly lit environment.