

INSTALLATION INSTRUCTIONS



Lights.com

IMPORTANT

Before using your LampLust Frosted Solar Rock Light, please make sure that you carefully read through these instruction sheets.


NOTE: The important safeguards and instructions that appear in this manual are not meant to cover all possible conditions and situations that may occur. It must be understood that common sense, caution and care are factors that can't be built into any product. This approach must be used by the person(s) caring for and operating the solar light.

GENERAL INFORMATION


Battery installation should only be performed by an adult. Only batteries of the same or equivalent type as recommended should be used. Battery leakage can cause corrosion and damage to this product so please remove non-functioning batteries immediately. Remove batteries from product during long periods of non-use. DO NOT DISPOSE OF IN FIRE. Please dispose at your local recycling facility.

STEP BY STEP INSTRUCTIONS

Before operating your solar light, remove packaging and ensure that the switch on the bottom of the light has been switched "ON." The light must be turned on in order for the battery to charge.



1



MODEL NO.

LC004061

LC004065

WHAT WE PROVIDE


- Frosted Solar Rock Light
- 1 AAA NI-MH Rechargeable Battery (Installed)

SOLAR CHARGING

Maximum sunlight will give the internal battery the best charge and give you the best results. Position the solar light out in the open, where it is free from any cover or shade. Avoid proximity to other light sources, which may cause the solar light to not operate correctly. If using more than one solar light, allow at least 6 feet between lights. The solar light will not be very bright or long lasting, until the battery is fully charged.

NOTE: You may charge the battery in a battery charger, or charge it with the solar panel. When using the solar panel, be sure that the battery receives a full day's worth of sunlight before use.

INSTALLATION INSTRUCTIONS



2

BATTERY REPLACEMENT

Batteries may need replacement every 1-2 years, depending on the operating conditions. To install a new battery, unscrew the panel on the bottom. When installing a new battery, be sure to insert with the correct polarity as indicated (+/-) and secure battery compartment before use.

TROUBLESHOOTING

Solar lights not operating properly at night may be caused by one of the following conditions:

- The switch may not be switched to "ON." Ensure that the switch has been moved to the "ON" position.
- Low light levels during the day, caused by the position in which the light is placed, or lack of sunlight, will shorten the solar light's operating time at night.
- If the surface of the solar light is dirty, the charging ability will be reduced. Clean the surface occasionally with a damp cloth.
- The batteries might need to be replaced. In the event that they do need replacing, see "BATTERY REPLACEMENT" above.
- Please note that solar lights will not function in the daytime or in a brightly lit environment.